

Prawn Launch User Instructions

Everyone using this launch **MUST wear buoyancy aid or life jacket**. No smoking on board.

Before starting check

- fuel level (half tank plus)
- ensure seacock is open.
- water inlet strainer (clean)
- bilge pump (in engine box, clean and running)
- water level (header tank in engine box)
- **DO NOT** touch if engine hot. The key to the key box also opens engine cover

To Start

- insert the two battery keys and turn on
- pull out throttle to put engine in neutral then tilt slightly forward
- insert ignition key
- turn ignition key to the left and hold for 10 seconds
- turn ignition key to the right to start engine
- pull back throttle to centre, untie boat and go

To Stop

- press black “stop” button on control panel until engine stops then remove key
- in bad weather or if it is forecast, moor bow to wind or at Lobster Quay

Any Problems?

Please leave a note in the book and inform the Club Office *admin@warsashsc.org.uk* or voicemail on 01489583575